

LanSafe 6.0.4 for Windows

Windows 2000 (Server, Advanced Server, Professional)

Windows XP Home
Windows XP Professional ¹

Windows 2003 Server (Web, Small Business, Standard, Enterprise) ^{1,2}
Windows 2003 Server R2 (Standard, Enterprise) ¹

Windows Vista (Ultimate, Home Premium, Business) ¹

Windows Server 2008 ¹
Windows Server 2008 R2 ²

Windows 7 ¹

LanSafe 6.0.3 for Linux

Red Hat Enterprise Linux
v 3 (ES and AS)
v 4 and 5 (ES, AS, and Desktop) ¹

Fedora Core 5 and 6 ¹
Fedora Core 7 and 8 ²

SuSE
Linux 8, 9 and 10 ¹
Enterprise Linux Server 8, 9 and 10 ¹

VMware ESX Server 3.5

LanSafe 6.0.0 for Unix

AIX (6.0.0)
V 5.1, 5.2, 5.3 for IBM PowerPC 4 and 5 ²
v 6.1 for IBM PowerPC 5 ²

HP-UX (6.0.0)
v 11.0, 11i (11.11) for PA-RISC ²
v 11i v1.6 (11.22) for Itanium2 ²
v 11i v2 (11.23) for Itanium2 ²

SCO Unix OpenServer (6.0.0)
v 5.0.6, 5.0.7

SGI Irix (MIPS) (6.0.0)
V 6.5.2.x ¹

LanSafe 6.0.3 for Unix

Mac OS
V 10.2.8, 10.3.x, 10.4.x

Sun Solaris
v 7, 8, 9, 10 for SPARC

LanSafe 6.0.4 for Unix

Sun Solaris
v 7, 8, 9, 10 for Intel (6.0.4)

LanSafe 6.0.3 for Novell NetWare

Novell NetWare
v 5.0, 5.1, 6.0, 6.5

* Check www.eaton.com/powerquality for most recent software updates and versions

Jan 12, 2010

¹ Supports 32- and 64-bit processors

² Supports 64-bit processors